



PS00021307A01

GL21-4AD1DA-V

Analog Voltage Input and Output Expansion Card

User Guide

Suzhou Inovance Technology Co., Ltd.

Add.: No. 52, Tian E Dang Road, Wuzhong District, 215104,

Suzhou City, Jiangsu Province, P.R. China

Tel: (0512) 6637 6666 Fax: (0512) 6285 6720

www.inovance.com



Legal Information

■ Copyright

Copyright © 2025 Shenzhen Inovance Technology Co., Ltd. All rights reserved.

This documentation is the exclusive property of Shenzhen Inovance Technology Co., Ltd. No individual or entity may excerpt, reproduce, modify, translate, or distribute any content herein without written consent from Inovance.

Legal action will be taken against infringement.

■ Trademarks

INOVANCE is a registered trademark of Shenzhen Inovance Technology Co., Ltd. and its affiliated companies. All other trademarks or registered trademarks mentioned in this documentation are the property of their respective owners. Unauthorized use of these trademarks by third parties for any purpose without written authorization could violate the rights of their owners.

■ Disclaimer of Liability

Due to continuous updates and improvements of products and technologies, the content of this documentation may not fully match the actual products. In the event of any discrepancies, the actual products shall prevail.

The contents are subject to change without notice due to product upgrade.

■ Waste Disposal

The storage, use, and disposal of this product (including optional accessories) must comply with local laws and regulations.

■ Qualified Personnel

The product/system described in this documentation may be operated only by personnel qualified for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions. Qualified personnel can identify the risks of the product/system and prevent possible dangers.

■ Proper Use of the Product

Proper transportation, storage, assembly, installation, commissioning, operation, and maintenance are required to ensure the safe operation of the product without any problems. The required ambient conditions must be met. All operations must follow the guidelines provided in this documentation.

Preface

■ Introduction

This guide presents the product information, installation, wiring, and configuration and commissioning of the product. Read this guide carefully before using the product to ensure safe operation.

■ Standards compliance

The following table lists the certifications, directives, and standards that the product may comply with. For details about the acquired certificates, see the certification marks on the product nameplate.

Certification	Directive		Standard
CE certification	EMC directive	2014/30/EU	24 VDC products: EN 61131-2 220 VAC products: EN 61131-2 EN 61000-3-2 EN 61000-3-3
	LVD directive	2014/35/EU	EN 61010-1 EN 61010-2-201
	RoHS directive	2011/65/EU amended by (EU) 2015/863	EN IEC 63000
UL/cUL certification	-		UL 61010-1 UL 61010-2-201 CAN/CSA-C22.2 No. 61010-1 CSA C22.2 NO. 61010-2-201
KCC certification	-		-
EAC certification	-		-

Certification	Directive		Standard
UKCA certification	Safety regulations	Electrical Equipment (Safety) Regulations 2016	EN 61010-1 EN 61010-2-201
	EMC regulations	Electromagnetic Compatibility Regulations 2016	24 VDC products: EN 61131-2 220 VAC products: EN 61131-2 EN 61000-3-2 EN 61000-3-3
	RoHS regulations	Directive (RoHS) Regulations 2012	EN IEC 63000

■ More documents

Document	Code	Description
Easy321 & Easy511 Programmable Logic Controller User Guide	PS00017976	Presents the information about all use scenarios of Easy321 and Easy511 series products, including product introduction, installation, wiring, configuration and commissioning, product features, fault diagnosis, maintenance, and appendix.
Easy321S Programmable Logic Controller User Guide	PS00021275	Presents the information about all use scenarios of Easy321S series products, including product introduction, installation, wiring, configuration and commissioning, product features, fault diagnosis, maintenance, and appendix.
H5U & Easy Series Programmable Logic Controller Programming Guide	19012249	Presents the basic knowledge of PLC programming, quick start guidance, communication, motion control, and use of high-speed counters.

Document	Code	Description
H5U & Easy Series Programmable Logic Controller Instruction Guide	19012250	Presents the basic and complex instructions used for programming applications, as well as examples of these instructions.
GE21-4AD1DA-V Analog Voltage Input and Output Expansion Card User Guide (the present guide)	PS00021307	Presents the product information, installation, wiring, and configuration and commissioning of the product.

■ Revision history

Revision date	Version	Description of change(s)
2025-11	A01	Updated <i>"1.4.5 Digital Limit Specifications" on page 19.</i>
2025-08	A00	First release.

■ Access to the guide

This guide is not delivered with the product. You can obtain the PDF version in the following ways:

- Visit <https://www.inovance.com/global>, choose Service&Support > Support > Documentation Download.
- Scan the QR code on the product with your smart phone.
- Scan the QR code below to install the My Inovance app, where you can search for and download user guides.



■ Warranty

Inovance provides warranty service within the warranty period (as specified in your order) for any fault or damage that is caused by proper operation of the user. Maintenance will be charged after the warranty expires.

Even within the warranty period, maintenance will be charged for the following product damage:

- Damage caused by operations not following the instructions in the guide
- Damage caused by fire, flood, and unusual voltage
- Damage caused by using the product for unintended functions
- Damage caused by using the product outside the specified scope
- Secondary damage caused by force majeure (natural disaster, earthquake, lightning strike)

When applicable, relevant maintenance fee will be charged according to the latest Price List of Inovance. If otherwise agreed upon, the agreed terms and conditions shall prevail.

For details, see the Warranty Card.

Fundamental Safety Instructions

■ Safety disclaimer

- This chapter provides essential safety instructions for proper use of the product. Before operating the equipment, read through the guide and comprehend all the safety instructions. Failure to comply with the safety precautions may result in death, serious injury, or equipment damage.
- "DANGER", "WARNING", and "CAUTION" items in the user guide do not indicate all safety precautions that need to be followed. Instead, they just supplement the safety precautions.
- Use this equipment according to the designated environment requirements. Damage caused by improper use is not covered by warranty.
- Inovance shall take no responsibility for any personal injuries or property damage caused by improper use.

■ Safety levels and definitions



DANGER

Indicates that failure to comply with the notice can result in death or severe personal injuries.



WARNING

Indicates that failure to comply with the notice may result in severe personal injuries or even death.



CAUTION

Indicates that failure to comply with the notice may result in minor or moderate personal injuries or equipment damage.

■ Safety precautions

- Drawings in the guide are sometimes shown without covers or protective guards. Install the covers or protective guards as specified first, and then perform operations in accordance with the instructions.
- The drawings in the guide are shown for illustration only and may be different from the product you purchased.
- Operators must take mechanical precautions to protect personal safety and wear protective equipment, such as anti-smashing shoes, safety clothing, safety glasses, protective gloves, and protective sleeves.

Unpacking



WARNING

- Do not install the equipment if you find damage, rust, or signs of use on the equipment or accessories upon unpacking.
- Do not install the equipment if you find water seepage or missing or damaged components upon unpacking.
- Do not install the equipment if you find the packing list does not conform to the equipment you received.



CAUTION

- Check whether the packing is intact and whether there is damage, water seepage, dampness, and deformation before unpacking.
- Unpack the package in accordance with the package sequence. Do not hit the package with force.
- Check whether there is damage, rust, or injuries on the surface of the equipment and equipment accessories upon unpacking.
- Check whether the package contents are consistent with the packing list after unpacking.

Storage and transportation



WARNING

- Large-scale or heavy equipment must be transported by qualified professionals using specialized hoisting equipment. Failure to comply may result in personal injury or equipment damage.
- Before hoisting the equipment, ensure the equipment components such as the front cover and terminal blocks are secured firmly with screws. Loosely-connected components may fall off and result in personal injuries or equipment damage.
- Never stand or stay below the equipment when the equipment is being hoisted by the hoisting equipment.
- When hoisting the equipment with a steel rope, ensure the equipment is hoisted at a constant speed without suffering from vibration or shock. Do not turn the equipment over or let the equipment stay hanging in the air. Failure to comply may result in personal injuries or equipment damage.



CAUTION

- Handle the equipment with care during transportation and mind your steps to prevent personal injuries or equipment damage.
- When carrying the equipment with bare hands, hold the equipment casing firmly with care to prevent parts from falling. Failure to comply may result in personal injuries.
- Store and transport the equipment based on the storage and transportation requirements. Failure to comply can result in equipment damage.
- Do not store or transport the drive in environments with water splash, rain, direct sunlight, strong electric field, strong magnetic field, and strong vibration.
- Do not store the drive for more than three months. Long-term storage requires stricter protection and necessary inspections.
- Pack the drive strictly before transportation. Use a sealed box for long-distance transportation.
- Never transport the equipment with other device or materials that may harm or have negative impacts on the equipment.

Installation



DANGER

- The equipment must be operated only by professionals with electrical knowledge. Non-professionals are not allowed.



WARNING

- Read through the guide and safety instructions before installation.
- Do not install this equipment in places with strong electric or magnetic fields.
- Before installation, check that the mechanical strength of the installation site can bear the weight of the equipment. Failure to comply will result in mechanical hazards.
- Do not wear loose clothes or accessories during installation. Failure to comply may result in an electric shock.
- When installing the equipment in a closed environment (such as a cabinet or casing), use a cooling device (such as a fan or air conditioner) to cool the environment down to the required temperature. Failure to comply may result in equipment over-temperature or a fire.
- Do not retrofit the equipment.
- Do not fiddle with the bolts used to fix equipment components or the bolts marked in red.
- When the equipment is installed in a cabinet or final assembly, a fireproof enclosure providing both electrical and mechanical protections must be provided. The IP rating must meet IEC standards and local laws and regulations.
- Before installing devices with strong electromagnetic interference, such as a transformer, install a shielding device for the equipment to prevent malfunction.
- Install the equipment onto an incombustible object such as a metal. Keep the equipment away from combustible objects. Failure to comply will result in a fire.



CAUTION

- Cover the top of the equipment with a piece of cloth or paper during installation. This is to prevent unwanted objects such as metal chippings, oil, and water from falling into the equipment and causing faults. After installation, remove the cloth or paper on the top of the equipment to prevent over-temperature caused by poor ventilation due to blocked ventilation holes.
- Resonance may occur when the equipment operating at a constant speed executes variable speed operations. In this case, install the vibration-proof rubber under the motor frame or use the vibration suppression function to reduce resonance.

Wiring



DANGER

- Equipment installation, wiring, maintenance, inspection, or parts replacement must be performed only by professionals.
- Before wiring, cut off all the power supplies of the equipment. Wait for at least the time designated on the equipment warning label before further operations because residual voltage still exists after power-off. After waiting for the designated time, measure the DC voltage in the main circuit to ensure the DC voltage is within the safe voltage range. Failure to comply can result in an electric shock.
- Do not perform wiring, remove the equipment cover, or touch the circuit board with power on. Failure to comply can result in an electric shock.
- Check that the equipment is grounded properly. Failure to comply can result in electric shock.



WARNING

- Do not connect the input power supply to the output end of the equipment. Failure to comply will result in equipment damage or even a fire.
- When connecting a drive to the motor, check that the phase sequences of the drive and motor terminals are consistent to prevent reverse motor rotation.
- Cables used for wiring must meet cross-sectional area and shielding requirements. The shield of the cable must be reliably grounded at one end.
- Fix the terminal screws with the tightening torque specified in the user guide. Improper tightening torque may overheat or damage the connecting part, resulting in a fire.
- After wiring is done, check that all cables are connected properly and no screws, washers or exposed cables are left inside the equipment. Failure to comply may result in electric shock or equipment damage.



CAUTION

- Follow the proper electrostatic discharge to perform wiring. Failure to comply may result in damage to the equipment or to the internal circuit of the product.
- Use shielded twisted pairs for the control circuit. Connect the shield to the grounding terminal of the equipment for grounding purpose. Failure to comply will result in equipment malfunction.

Power-on



DANGER

- Before power-on, check that the equipment is installed properly with reliable wiring and the motor can be restarted.
- Check that the power supply meets equipment requirements before power-on to prevent equipment damage or a fire.
- After power-on, do not open the cabinet door or protective cover of the equipment, touch any terminal, or disassemble any unit or component of the equipment. Failure to comply will result in an electric shock.



WARNING

- Perform a trial run after wiring and parameter setting to ensure the equipment operates safely. Failure to comply may result in personal injuries or equipment damage.
- Before power-on, check that the rated voltage of the equipment is consistent with that of the power supply. Failure to comply may result in a fire.
- Before power-on, check that no one is near the equipment, motor, or machine. Failure to comply may result in death or personal injuries.

Operation



DANGER

- The equipment must be operated only by professionals. Failure to comply will result in death or personal injury.
- Do not touch any connecting terminals or disassemble any unit or component of the equipment during operation. Failure to comply will result in an electric shock.



WARNING

- Do not touch the equipment enclosure, fan, or resistor with bare hands. Failure to comply may result in personal injury.
- Prevent metal or other objects from falling into the equipment during operation. Failure to comply may result in a fire or equipment damage.

Maintenance



DANGER

- Equipment installation, wiring, maintenance, inspection, or parts replacement must be performed only by professionals.
- Do not maintain the equipment with power ON. Failure to comply will result in an electric shock.
- Before maintenance, cut off all the power supplies of the equipment and wait for at least the time designated on the equipment warning label.
- In case of a permanent magnet motor, do not touch the motor terminals immediately after power-off because the motor terminals will generate induced voltage during rotation even after the equipment power supply is off. Failure to comply will result in an electric shock.



WARNING

- Perform routine and periodic inspection and maintenance on the equipment according to maintenance requirements and keep a maintenance record.

Repair



DANGER

- Equipment installation, wiring, maintenance, inspection, or parts replacement must be performed only by professionals.
- Do not repair the equipment with power ON. Failure to comply can result in an electric shock.
- Before inspection and repair, cut off all the power supplies of the equipment and wait for at least the time designated on the equipment warning label.



WARNING

- Submit the repair request according to the warranty agreement.
- When the fuse is blown or the circuit breaker or earth leakage circuit breaker (ELCB) trips, wait as specified on the product warning sign before power-on or further operations. Failure to comply may result in personal injuries, equipment damage or even death.
- When the equipment is faulty or damaged, require professionals to perform troubleshooting and repair by following repair instructions and keep a repair record.
- Replace quick-wear parts of the equipment according to the replacement instructions.
- Do not use damaged equipment. Failure to comply may result in death, personal injuries, or severe equipment damage.
- After the equipment is replaced, check the wiring and set parameters again.

Disposal



WARNING

- Dispose of retired equipment in accordance with local regulations and standards. Failure to comply may result in property damage, personal injury, or even death.
- Recycle retired equipment by observing industry waste disposal standards to avoid environmental pollution.

■ Safety label

For safe equipment operation and maintenance, comply with the safety labels on the equipment. Do not damage or remove the safety labels. The following table describes the meaning of the safety labels.

To ensure safe operation, comply with equipment-related safety labels. The following table describes the meaning of the safety labels.

Safety label	Description
	• Read through the safety instructions before operating the equipment. Failure to comply may result in death, personal injuries, or equipment damage. • Caution: Product surface is hot. Avoid burns! • Do not touch the terminals or remove the cover with power ON or within 10 min after power-off. Failure to comply will result in an electric shock.

1 Product Information

1.1 Product Overview

GE21-4AD1DA-V expansion card is independently developed by Inovance. It is designed to be used with the Easy321, Easy511, and Easy321S series PLCs, and supports four analog inputs and one analog output (voltage type).

1.2 Model and Nameplate

Model

GE21-4AD1DA-V

①

②

③

① **Product series**

General-purpose expansion card
21

③ **Product code**

Voltage type

② **Product code**

Expansion card with four analog
inputs and one analog output

-

Nameplate



Note

The letters "A" and "B" on the nameplate indicate that the card slots A and B of the PLC are supported.

Model	Description	Code
GE21-4AD1DA-V	GE21 series expansion card with four analog inputs and one analog output (voltage type)	01480071

1.3 Components



No.	Terminal type	Identification	Definition	Indicator color	Description
①	Power supply indicator	PWR	Normal power supply	Yellow-green	ON when the expansion card is powered on.
②	User terminal	-	-	-	For details, see "3.1 Terminal Assignment" on page 26

1.4 Product Specifications

1.4.1 General Specifications

Item	Description
IP rating	IP20
Dimensions (W × H × D)	58 mm × 42 mm × 21.4 mm
Weight	Approx. 26 g

1.4.2 Power Supply Specifications

Item	Description
Rated input voltage	5 VDC (4.75 VDC to 5.25 VDC)
Rated input current	65 mA (max@5 V)
Input short-circuit protection	Supported
Hot swap	Not supported

1.4.3 Input Specifications

Item	Description
Number of input channels	4
Voltage input range	0 V to 10 V
Voltage input impedance	> 200 kΩ

Item	Description
Conversion speed	6 ms/channel
Current input range	0 mA to 20 mA
Current sampling impedance	250 Ω
Input accuracy (25°C)	Voltage: $\pm 1\%$; current: $\pm 1\%$ (full range)
Input accuracy (full temperature range)	Voltage: $\pm 3\%$; current: $\pm 3\%$ (full range)
Input signal frequency	< 10 Hz
Resolution	12bit
Digital output	0–20000

1.4.4 Output Specifications

Item	Description
Number of output channels	1
Voltage output range	0 V to 10 V
Voltage output load	> 2 k Ω
Conversion speed	1 ms
Output accuracy (25°C)	$\pm 1\%$ (full range)
Output accuracy (full temperature range)	$\pm 5\%$ (full range)
Resolution	12bit
Digital output	0–20000

1.4.5 Digital Limit Specifications

The following table shows the digital value ranges and limit ranges corresponding to the input and output specifications of analog voltage and analog current.

Analog	Rated range	Corresponding digital value	Limit range	Corresponding digital value
Analog voltage output	0 V to 10 V	0 to 20000	0 V to 10.5 V	0 to 21000
	0 V to 5 V	0 to 20000	0 V to 5.25 V	0 to 21000
	1 V to 5 V	0 to 20000	1 V to 5.2 V	0 to 21000
Analog current output	0 mA to 20 mA	0 to 20000	0 mA to 21 mA	0 to 21000
	4 mA to 20 mA	0 to 20000	4 mA to 20.8 mA	0 to 21000
Analog voltage input	0 V to 10 V	0 to 20000	0 V to 10.5 V	0 to 21000
	0 V to 5 V	0 to 20000	0 V to 5.25 V	0 to 21000
	1 V to 5 V	0 to 20000	1 V to 5.2 V	-1 to 21000
Analog current input	0 mA to 20 mA	0 to 20000	0 mA to 21 mA	0 to 21000
	4 mA to 20 mA	0 to 20000	4 mA to 20.8 mA	-1 to 21000

1.4.6 Other Specifications

Item	Description
Sampling cycle	1 ms
Communication cycle with PLC (AutoShop)	- High-speed mode: ≤ 6 ms (modification of channel mapping elements is not supported) - Normal mode: ≤ 20 ms (modification of channel mapping elements is supported)
Isolation mode	Non-isolation
Output short-circuit detection	Not supported
Output open-circuit detection	Not supported

1.5 Environmental Specifications

Item	Specification
Working environment	Free from conductive dust, conductive fibers, explosive dust, flammable gases, water mist/greasy dirt, corrosive dust/gases, strong vibration, and repetitive shock
Altitude	≤ 2000 m
Pollution degree	Level 2

Item	Specification
Immunity	2 kV on power supply line (Conforms to IEC 61000-4-4)
Overvoltage category	I
EMC immunity level	Zone B, IEC61131-2
Anti-static rating	Contact discharge +/-6 kV and air discharge +/-8 kV
Vibration resistance	● Application scenario: Tested according to IEC60068-2-6. 3.5 mm amplitude at 5 Hz to 8.4 Hz; 1 g acceleration at 8.4 Hz to 200 Hz; in ten cycles/axis ● Transportation scenario: Tested according to IEC60068-2-64, 0.01 g²/Hz power spectral density at 5 Hz to 100 Hz; 0.001 g²/Hz power spectral density at 200 Hz; 1.14 g Grms
Shock resistance	Application/Transportation scenario: Tested according to IEC60068-2-27; 15 g peak gravitational acceleration; 11 ms pulse width; 18 times in X/Y/Z-axis directions
Operating temperature/humidity	● Temperature: -20 °C to +55 °C ● Humidity: < 95% RH (30°C), without condensation
Storage temperature/humidity	● Temperature: -20 °C to +60 °C ● Humidity: < 90% RH (30°C), without condensation
Transportation temperature/humidity	● Temperature: -40 °C to +70 °C ● Humidity: < 95% RH (40°C), without condensation


2 Installation

2.1 Precautions

- Make sure the PLC is powered off before installing or removing the expansion card.
- Hot plugging of the expansion card is prohibited, because it may lead to PLC restart and/or user data loss or corruption.
- Do not drop or impact the housing or terminals of the expansion card to prevent damage.

2.2 Mounting Dimensions

The mounting dimensions (in mm) are shown in the figure below.




2.3 Procedure


■ Installing the expansion card

The expansion card is snap-fitted with the PLC module.


1. Place the PLC horizontally, and align the expansion card module horizontally with it.



2. Insert the expansion card vertically into the card slot A or B (using the slot A as an example) of the PLC along the guide rib.




3. Press the expansion card with your hand. When you hear a click and the surface of the expansion card is flush with the surface of the PLC module, the installation is complete, as shown in the figure below.




■ Removing the expansion card


1. Place the PLC module horizontally and insert a straight screwdriver into the snap-fit position.



2. Pry the expansion card module in the direction indicated by the arrow.



3. Remove the expansion card module vertically when you hear a distinct sound indicating that the expansion card has partially detached from the PLC.



3 Wiring

3.1 Terminal Assignment



Terminal assignment	Description
V10+	Voltage/Current channel 0 input+
V10-	Voltage/Current channel 0 input-
V11+	Voltage/Current channel 1 input+
V11-	Voltage/Current channel 1 input-
V12+	Voltage/Current channel 2 input+
V12-	Voltage/Current channel 2 input-
V13+	Voltage/Current channel 3 input+
V13-	Voltage/Current channel 3 input-
V0+	Voltage channel output +
V0-	Voltage channel output-

3.2 Terminal Wiring


■ Precautions

- Do not bundle the extension cables with power cables (high voltage and high current) that produce strong interference signals, as this may increase noise,

surges, and induction effects. Separate the extension cables from the power cables and avoid cabling in parallel.


- Select recommended cables for connection. It is recommended that shielded cables be used as extension cables to enhance capacity of resisting interference.
- Apply single-point grounding for the shields of shielded cables and soldered cables.

■ External input wiring



- [1]: Use 2-conductor shielded twisted pair cables for analog signals.
- [2]: Current input is provided when the switch is closed, which is controlled by the software.

■ External output wiring




- [1]: Use a 2-conductor shielded twisted pair cable as the power cable.
- [2]: If noises or ripples are generated in external wiring, connect a 0.1–0.47 μF 25 V capacitor between terminals VO+ and VO-.

3.3 Cable Selection

The cable lug and sizes in the following table are provided for reference only.

Supporting material	Applicable cable size		Suzhou Yuanli	
	mm ²	AWG	Model	Crimping tool
Tubular lug	0.5	20	0508	YAC-5
	0.75	18	7508	

If another type of tubular lug is used, crimp the lug onto the stranded wire, as shown below.



3.4 Cable Connection

For selection of the cable with a tubular lug, see ["3.3 Cable Selection" on page 27](#). To secure the cable, insert it into an input/output terminal and tighten the screw with a straight screwdriver (Radius: 2 mm to 2.5 mm) or equivalent.

Note

Use a straight screwdriver to loosen the terminal screw and then pull out the cable during the removal.

4 Configuration and Commissioning


The following is an example of how to configure the Easy321-3624ER PLC and the GE21-4AD1DA-V expansion card in the AutoShop software.

Precautions


The GE21-4AD1DA-V expansion card type ID is 8. The configured expansion card must have the same type as the actually installed expansion card.

Procedure


1. Create a new project, define the "Project name" and "Save path", select proper product series and model following the "Series and models", and then click "OK".



2. In the left "Project Manager" pane, right-click "Config > EXP-A" or "Config > EXP-B" (depending on the position of the expansion card) and select "GE21-4AD1DA-V"; or right-click "Config > Module Config" and select "Auto Scan" to add the GE21-4AD1DA-V expansion card, as shown in the figure below.



3. In the left "Project Manager" pane, double-click "Config > EXP-A > GE21-4AD1DA-V". In the opened "EXP-A" dialog box, enable the channel on the "Config" tab, and configure the "Transform mode" and "Filter parameters".



The parameters for channel configuration are shown in the following table.

Parameter	Description	Settings
Enable channel	Channel enable status	• Enabled when the option is checked. • Disabled when the option is not checked.
Transform mode	Voltage/Current range	The following ranges are supported for input channels 0 to 3: • 0–10 V (0–20000) • 0–5 V (0–20000) • 1–5 V (0–20000) • 0–20 mA (0–20000) • 4–20 mA (0–20000) The following ranges are supported for output channel 4: • 0–10 V (0–20000) • 0–5 V (0–20000) • 1–5 V (0–20000)
Filter parameters	The larger the parameter value, the stronger the filtering effect.	Range: 0–255
Output status after stop	Output status of the module when the PLC stops running	• Output zeroing: The output value is reset to zero. • Output remains: The output value remains unchanged. • Output preset value: The output value is set to the preset value.

4. Perform IO mapping.




Caution

- GE21 series expansion cards operate in high-speed mode by default.
- High-speed mode: ≤ 6 ms (modification of channel mapping elements is not supported)
- Normal mode: ≤ 20 ms (modification of channel mapping elements is supported)

In the left "Project Manager" pane, double-click "Config > EXP-A>GE21-4AD1DA-V". In the opened dialog box, select "IO Mapping" tab, in which the channel IO is mapped to the system variable `_ExtCard` structure by default.

EXP-A(GE21-4AD1DA-V)



5. After successful compiling, download the project and run it.


- Click  in the toolbar to download the program to the PLC.
- After the download is complete, click  in the toolbar to run the program.

Note


In Step 4, the procedure for IO mapping in normal mode is as follows.

1. Select high-speed mode or normal mode.

- a. In the left "Project Manager" pane, go to "Config", right-click the added expansion card, and select "Property".



- b. In the opened dialog box, select "Normal mode" and click "OK".



2. Perform IO mapping.

- a. In the left "Project Manager" pane, double-click "Config > EXP-A>GE21-4AD1DA-V". In the opened dialog box, select "IO Mapping" tab and double-click  to configure the channel IO mapping for the GE21-4AD1DA-V expansion card (mapping to the system variable _ExtCard structure by default).

Config IO Mapping

Channel Mapping Element	Channel	Type
... _ExtCard[0] AD0	CH0	INT
... _ExtCard[0] AD1	CH1	INT
... _ExtCard[0] AD2	CH2	INT
... _ExtCard[0] AD3	CH3	INT
... _ExtCard[0] DA0	CH4	INT

OK

b. In the opened dialog box, select the D element.

Variable Input Assistant

Element name: D47

Search

Expand Node

Shrink Node

OK

- _SYS_COM_SAV
- _SYS_ECATA_MA
- _SYS_ECATA_SLA
- _SYS_ETHERNET
- _SYS_INFO
- _SYS_PN

- ECam
- Axis
- ECATSlave
- MbTcp

- UserVar
 - FUNCTION BLOCK
 - SYS_EIP
 - SYS_ETHERCAT
 - VARIABLE_TABL

- SoftElem

- BitElem
 - ...X(0-1777)
 - ...Y(0-1777)
 - ...B(0-32767)
 - ...M(0-7999)
 - ...S(0-4095)
- WordElem
 - ...D(0-7999)
 - ...R(0-32767)
 - ...W(0-32767)

	Element Name	Data Type	Comment
37	D36	INT DINT REAL	
38	D37	INT DINT REAL	
39	D38	INT DINT REAL	
40	D39	INT DINT REAL	
41	D40	INT DINT REAL	
42	D41	INT DINT REAL	
43	D42	INT DINT REAL	
44	D43	INT DINT REAL	
45	D44	INT DINT REAL	
46	D45	INT DINT REAL	
47	D46	INT DINT REAL	
48	D47	INT DINT REAL	
49	D48	INT DINT REAL	
50	D49	INT DINT REAL	
51	D50	INT DINT REAL	
52	D51	INT DINT REAL	
53	D52	INT DINT REAL	
54	D53	INT DINT REAL	
55	D54	INT DINT REAL	
56	D55	INT DINT REAL	

- c. After the configuration is complete, click "OK" to map the channel IO to an unused D element, as shown in the figure below.

EXP-A(GE21-4AD1DA-V)

Config

IO Mapping

Channel Mapping Element	Channel	Type
☐ D47		
☐ D47	CH0	INT
☐ D48	CH1	INT
☐ D49	CH2	INT
☐ D50	CH3	INT
☐ D51	CH4	INT

OK

Services and Support

Should you encounter a safety accident during the use or operation of the product, or face challenges in operating and maintaining the equipment, which remain unresolved after the relevant documentation is consulted, we provide multiple channels to ensure prompt resolution:

- Channel #1: Contact service@inovance.com.



- Channel #2: Visit <https://www.inovance.com/global> to access document downloads, after-sales support, spare parts ordering, repair applications, and authenticity verification services.
- Channel #3: Download My Inovance app (<https://zshc-eu.inovance.com/download-pc/>) where you can access products info and documentation, and query product parameters.

We are committed to providing you with quick and professional technical support, and we look forward to your satisfaction and trust.